

LSP Aspirator Unit

Spare Parts List

LSP Aspirator - Model 146 Aspirator Parts List

Drawing No	LSP No	Our Number	Description
24	L535026	55-604-08	Hose Assy.
20	L435620-252	55-604-04	Set Screw
17	L150052	55-604-01	Button
15	L435050-060	55-604-03	Set Screw, Self Locking
14	L475016	55-901-10	Aspirator Jar
13	L577091	55-604-13	Spring, Poppet
10	L525100	55-604-05	Fitting Inlet
9	L560646-004	55-604-12	O-Ring
8	L560645-008	55-604-10	O-Ring
7	L560645-011	55-604-11	O-Ring
6	L525125	55-604-07	Stem
5	L585056	55-604-14	Poppet
4	L560042	55-604-09	Gasket
3	L595047	55-604-15	Orifice
3A		55-908	Venturi Redirector
2	L525124	55-604-06	Tube
1	L002948	55-604-02	Body